

Installation instructions

Wet bonding

IMPORTANT! The following instructions for a wet bonding we'd like to point out that we do not assume liability if your device "under water" and thus damage. If possible, remove the battery from the device or applied to build the device so apart that only the display to obtain in the hand.

Dear Customer, Dear Customer, We're delighted that you are for our high-quality Products have chosen. You have we get content following letter:

1. Display Protector / Laminate / felt squeegee purchased at the auction
2. VAT invoice with proven
3. Mounting aid sheet (evident in the checkered paper)
4. Note where you our detailed installation instructions can be found.

With the Digital Ultra Clear you have a film with high technical standard and quality purchased. This product is characterized by simple and easy assembly and excellent protection against scratches, abrasions and UV radiation. We hope you enjoy your new screen protector and thank you for the purchase of our product and the trust.

Help your assembly parts are into strips. We recommend strip of about 1cm wide x 2.5 cm in length. These strips can be used quite often and when should you obtain help, so you eg no fingerprints on the adhesive side of the foil leaves. Of course you can slide even without the help unravel the assembly.

Put the paper from the underside of the assembly line and stick to these strips on the protective screen. Place the strips with enough overhang so that you have sufficient space to touch you.



The stripes when you should obtain help so you do not have fingerprints on the adhesive side of the foil leaves.

Next, you clean your screen thoroughly, it should be bold and dust-free. Use this a cleaning cloth. Please do not use paper towels.



Imagine a flat plate with a mixture of water and a drop of soap cope. The further you take a strip of the assembly sheets. These strips can also be used more often. The patrols will help you when you obtain, so you do not have fingerprints on the adhesive side of the foil leaves. Gluing now installers stripes on the screen protector.

Take the foil strip to the prison and pull the institution back from a bit of material. If you just touch the mounting strip, you keep the protective against unnecessary fingerprints. Perform the foil sheets through the liquid and shaking the excess water. Now the film on the display will be. Through the water-soap mixture, you have the opportunity to display protection in the optimal position, without which the film moves or has already stuck and removing traces of leaves.



Rub the Screen protector from the center outward and then press the moisture out. The remaining moisture can dry out and then alone, in which you display labels in a warm place for two / three hours lagerst (eg on the heater).

Remove to end the prison stripes. It can be easily and without residues of the slide off. This method is suitable for all of our films and laminates species. You'll excited by the perusal.



FOLIEN
deluxe

 **FREYZEICHEN**
www.FREYZEICHEN.COM
Wer b e t e c h n i k